

AIRFIELD	ID	COORDINATES	ICAO	RWY	ALT Feet	VOR	TWR / RADIO	APP.	GND / APRON	REMARKS
Aeroden Lodge	UP	S25° 43' 19" E27° 44' 22"		17/35	4025					Permission: 060 663 6053
Aeropark Zynkraal	UP	S25° 54' 11" E28° 32' 48"		09/27	4976		125.4			Stephan: 083 679 7798 / Tarred
Aggeneys	L	S29° 16' 45" E18° 49' 03"	FAAG	07/25	2648	AGV116.7				Info: 082 771 3328
Airspan Executive Aerodrome	UP	S25° 45' 54" E27° 19' 21"		03/21	3900					Hrs: 07h00 - 17h00 daily / Barry: 082 899 2839
										Power lines East of runway
Alexander Bay	L	S28° 34' 24" E16° 32' 04"	FAAB	01/19	98	ABV112.1	118.7			Info - Louis: 082 772 7211
Aliwal North	L	S30° 41' 00" E26° 44' 00"	FAAN	06/24	4410					Info - Jurie: 078 340 5764
Alkantpan Test Range	L	S29° 55' 59" E22° 15' 57"	FACO	14/32	3530					Prior notice: 053 355 5000
Aviators Paradise	L	S25° 41' 38" E27° 46' 57"	FAAP	03/21	3800					
Bapsfontein	UP	S25° 59' 22" E28° 25' 00"		01/19	5300					Listen 120.35 / Microlights
Baragwanath (Syferfontein)	U	S26° 20' 47" E27° 46' 31"	FASY	13/31	5425		122.35			Aerobatics South West 122.35
Barberton	UP	S25° 42' 47" E30° 58' 23"	FABR	17/35	2250		123.95			Info - Curtis: 084 019 8574
Benoni / Brakpan	L	S26° 14' 34" E28° 18' 03"	FABB	18/36	5350		122.7			
Bethlehem	L	S28° 14' 55" E28° 20' 10"	FABM	13/31	5575					High ground West of airfield
Bhisho	L	S32° 53' 42" E27° 17' 06"	FABE	08/26	1950		120.6			
Bothaville	U	S27° 22' 00" E26° 38' 00"	FABO	07/25	4236					No runway lights / 056 514 9200
Bram Fischer International (Bloemfontein)	L	S29° 05' 38" E26° 18' 14"	FABL	02/20	4457	BLV114.1	120.8	124.3	122.65	Atis 126.45 - 02/20 Lights 3 clicks, 12/30 Lights 5 clicks 120.8
				12/30						
Brits	L	S25° 31' 57" E27° 46' 33"	FABS	02/20	3740		124.2			Gliding / Microlights: 071 444 0928
Bronkhorstspuit	vor	S25° 47' 27" E28° 33' 41"				MEV114.3				
Burgersdorp	L	S30° 59' 00" E26° 18' 00"	FABD	03/21	4715					051 653 1777 / 1834
Caledon	vor	S34° 06' 47" E19° 28' 40"				CDV114.9				
Calvinia	L	S31° 30' 01" E19° 43' 33"	FACV	09/27	3250					Info - L vd Merwe: 073 664 2099
Cape Town International	L	S33° 58' 17" E18° 36' 15"	FACT	01/19	151	CTV115.7	118.1 / 124.35	119.7	121.9	Atis 127.0 / Clearance delivery 122.1
				16/34			125.1		122.65	Cape Town Director: 124.35 high traffic
										Helicopters Dep & Arr: 121.9
Cape Winelands Airport	L	S33° 46' 17" E18° 44' 24"	FAWN	05/23	399			131.1		Join 2000ft / Circuit 1200ft
				14/32						076 126 3447 / Hayley: 083 505 5796
Carltonville	UP	S26° 22' 00" E27° 20' 48"	FACR	13/31	5000					
Carnarvon	L	S30° 59' 30" E22° 08' 00"	FACN	16/34	4150					053 382 3012
Carolina	U	S26° 04' 42" E30° 05' 34"	FACL	09/27	5425					Radio mast / 017 843 4000
Ceres	UP	S33° 18' 59" E19° 25' 37"	FACE	10/28	1900	CSV114.2				Perm - Marais: 082 896 3947
Clanwilliam	U	S32° 10' 45" E18° 52' 59"	FACW	17/35	425					027 482 8000
Cradock	U	S32° 09' 20" E25° 38' 45"	FACD	16/34	3142					
De Aar	L	S30° 41' 30" E24° 01' 27"	FADA	03/21	4154					Info - Louis: 083 411 7914
Delareyville	L	S26° 41' 00" E25° 28' 00"	FADL	04/22	4495					
Dendron	L	S23° 22' 50" E29° 19' 15"	FADO	09/27	3400					015 501 0243
Dundee	U	S28° 11' 00" E30° 13' 00"		18/36	4200					Prior notice - Tony: 082 821 7779
Dwaalboom	L	S24° 48' 26" E26° 49' 47"	FADB	06/24	3650					Permission: 014 778 9100
East London (King Phalo)	L	S33° 02' 06" E27° 49' 17"	FAEL	11/29	435	ELV114.5	118.3	120.1	122.65	Atis 126.65 / Info: 043 736 6161
				06/24						Birds on airfield
Ellisras (Lephalale)	UM	S23° 43' 36" E27° 41' 18"		09/27	2793	ERV116.3				Permission: 012 312 2034 / 2936
Emalahleni (Witbank)	L	S25° 50' 02" E29° 11' 33"	FAWI	04/22	5078	WIV113.3	123.5			Skydiving / 013 692 4021/2
Empangeni	L	S28° 43' 07" E31° 53' 34"	FAEM	04/22	238		118.9			Telephone lines
Ermelo	L	S26° 30' 00" E29° 59' 00"	FAEO	13/31	5800					Radio masts / Water Tower
Ernie's Field	UP	S31° 36' 22" E29° 31' 17"		07/25	1240					Cattle
Eshowe	U	S28° 52' 51" E31° 27' 20"	FAES	04/22	1700					Gerald: 082 781 3888